

System Power Switch ON / OFF

“P” Key

- Printing tickets (*system with onboard mobile printer*)
- Save data to USB port
- Waybill ID# input
- Decimal input (*used with parts count by weight*)

Scroll Keys (< >)

“F” Key

Operator Function Key (Press **F** and then **0** key)

- Bluetooth printer / scanner
- pairing functions
- TARE Function
- Parts count by weight
- Pounds or kilograms to be shown on LCD display



“Enter Key” ↵

Start Up

- * Turn on vehicle power switch. Turn on system power switch located on top of the instrument housing.
- * The LCD display will show software version, serial number and will indicate Date / Time.
(ED3 / ED4-EP SkidWeigh Plus check weighing scales without operator vehicle access control systems)
- * **SkidWeigh Plus Systems with Optional Operator Vehicle Access Controls**
System will prompt operator to input valid operator ID# or to scan operator RFID card.
- * Complete OSHA function, when applicable. *Default is (F) Fail. Use < > to change to (P) Pass and press Enter Key.*
- * LCD display will show Date / Time and vehicle will be operational

Operator Weighing Procedure

- **Lower loaded forks to ground**
- **LCD Display must show Date / Time**



- Activate **lift control switch** and **hold** it until the loaded forks are automatically stopped at the measurement height.
- Within few seconds load weight will be indicated on LCD Display.

Load Weight Measuring Cycle *(Single load or accumulative load weight total)*


- With LCD Display showing first load weight, press “Enter key” ↵ to start accumulating loads.
- The LCD Display will show first load weight. Keep lifting loads and press “Enter key” ↵.
- With each additional load lifted system will also show **TOTAL accumulative load weight**.
- On last load weight lifted press “Enter key” ↵ and press “P” key to complete the cycle.

Note: By pressing “P” key after single or the accumulative load weight shown on LCD display, the load weight measurement cycle will be reset.

Load weight information will be automatically saved to USB port, printed ticket provided if the Bluetooth onboard printer is utilized. Weighing data will be send to the base station.


Load Weight Measuring Cycle & Waybill *(Customer ID#, trailer ID#'s, etc.)*

- With LCD Display showing first load weight, press “Enter key” ↵ to start accumulating loads.
- The LCD Display will show first load weight. Keep lifting loads and press “Enter key” ↵.
- With each additional load lifted system will also show **TOTAL accumulative load weight**.
- On last load weight lifted press “Enter key” ↵ and press “P” key to advance to Waybill ID#.



Input first Waybill digit and press “Enter key” ↵.

Note: With each additional Waybill digit input into the system you must press “Enter key” ↵. With last Waybill digit input press “Enter key” ↵ **twice** to complete load weigh cycle with Waybill ID# information.



Note A: By pressing key “Enter key” ↵ **twice** after single or accumulative load weight shown on LCD display, the load cycle with Waybill ID# will be reset.

Load weight information with Waybill ID# will be automatically saved to USB port, printed ticket will be provided if the Bluetooth onboard printer is utilized. Weighing data will be send to the base station from ED4-EP SkidWeigh Plus Series.

Note B: With LCD Display is showing single load weight and by pressing “P” key you will advance to input the Waybill ID# into the system

With last Waybill digit input press “Enter key” ↵ to complete single load weight cycle with Waybill ID#.

Operator Functions Key

With LCD Display showing Date / Time press “F” key and than number 0.

Use < > **Key** to scroll for functions that are applicable on your system and follow instruction.

Use “Enter key” ↵ to confirm the application. Press “F” key to exit the menu.

a. **Weight Display** (LCD Display capability to show load weights in **pounds** or **kilograms**)

(Factory default setup is in pounds. Use < > **Key** to select and press “Enter key” ↵)

b. **Parts count**

(Input part weight. Use “P” key for decimal and press “Enter key” ↵. To reset part count input **1.0** and press “Enter key” ↵)

c. **TARE**

(Tare allocation is set to 0. Input new TARE value and “Enter key” ↵ to confirm. To reset TARE input **0** value and press “Enter key” ↵)

d. **Bluetooth Pairing**

(Bluetooth pairing for onboard printer or scanner has 3 modes, AUTO, MANUAL and INQUIRY. Use **INQUIRY** and press “Enter key” ↵ to initiate pairing process. Printer or scanner must be turned on. LCD Display will show **SEARCHING** and after few seconds LCD Display will show **FOUND 1**. Press “Enter key” ↵ and LCD Display will show **CONNECTING**.)



Bluetooth Icon

LCD Display will show Bluetooth icon when pairing is successful