

- **Turn on ignition switch**
(Without operator ID# function or RFID card reader the LCD Display will show Date / Time)
- **Note:** With LCD display showing “ENTER ID NUMBER” input valid operator ID # (Range 1 to 999), maximum 3 digits and press “Enter key” ↵
System equipped with RFID card reader, scan valid operator card. The LCD display will show Date / Time. **Vehicle operation will enabled and ready to operate.**



OSHA Safety Check

The OSHA safety check procedure will be automatically initiated every 8, 12 hours or daily which is specified in the management set up configuration.

Default value is (F) representing that safety check “fail”. Use arrow key (>) to toggle.

Press “Enter key” ↵ after choosing F or P.

F = Fail and P= Pass

Use arrow key (>) to scroll through the OSHA safety check menu.

After inputting the last OSHA safety check message LCD display will show Data / Time and vehicle will be operational.



OSHA safety menu

